

**TECHNICAL DATA**

## **A40B-ADAPT/LCN | Female to N Male inter-series adapter**



### **Product overview: A40B-ADAPT/LCN | Female to N Male inter-series adapter**

This adapter enables connecting the N-type input connectors of A40B shunts rated 20 A or less with sources that have male LC current connectors.

## Ordering information



### **A40B-ADAPT/LCN**

Female to N Male inter-series adapter

---



**Fluke.** *Keeping your world up and running.®*

**Fluke Corporation**  
PO Box 9090, Everett, WA 98206 U.S.A.

**For more information call:**  
In the U.S.A. (800) 443-5853  
In Canada (800) 36-FLUKE  
From other countries +1 (425) 446-5500  
[www.fluke.com](http://www.fluke.com)

©2025 Fluke Corporation.  
Specifications subject to change without notice.  
04/2025

**Modification of this document is not permitted  
without written permission from Fluke  
Corporation.**