

TECHNICAL DATA

Fluke BTL-A Voltage/Current Probe Adapter



Product overview: Fluke BTL-A Voltage/Current Probe Adapter

Voltage/current probe adapter for Fluke 500 Series Battery Analyzers. The BTL-A allows connection of standard 4mm banana plug test leads or current clamp adapter. Allows the BT521 Series Battery Analyzer to make AC and DC voltage and current measurements using the Fluke i410 AC/DC Current Clamp.

Ordering information



Fluke BTL-A

Voltage/Current Probe Adapter

Fluke. *Keeping your world up and running.®*

Fluke Corporation
PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:
In the U.S.A. (800) 443-5853
In Canada (800) 36-FLUKE
From other countries +1 (425) 446-5500
www.fluke.com

©2025 Fluke Corporation.
Specifications subject to change without notice.
04/2025

**Modification of this document is not permitted
without written permission from Fluke
Corporation.**