

## TECHNICAL DATA

# Fluke BTL-A Voltage/Current Probe Adapter



## Product overview: Fluke BTL-A Voltage/Current Probe Adapter

Voltage/current probe adapter for Fluke 500 Series Battery Analyzers. The BTL-A allows connection of standard 4mm banana plug test leads or current clamp adapter. Allows the BT521 Series Battery Analyzer to make AC and DC voltage and current measurements using the Fluke i410 AC/DC Current Clamp.

## Ordering information



### Fluke BTL-A

Voltage/Current Probe Adapter

---

**Fluke.** *Keeping your world up and running.®*

**Fluke Corporation**

PO Box 9090, Everett, WA 98206 U.S.A.

**For more information call:**

In the U.S.A. (800) 443-5853

In Europe/M-East/Africa

+31 (0)40 267 5100

In Canada (800)-36-FLUKE

From other countries +1 (425) 446-5500

**BUT. FLUKE SOUTH EAST ASIA PTE LTD**

Menera Satu Sentra Kelapa Gading #06-05

Jl. Bulevar Kelapa Gading Kav. LA# No. 1

Summarecon Kelapa Gading

Jakarta Utara 14240

Indonesia

Tel: +62 21 2938 5922

Email: info.asean@fluke.com

www.fluke.com/id-en

©2025 Fluke Corporation. Specifications subject to change without notice.

04/2025

**Modification of this document is not permitted without written permission from Fluke Corporation.**