

**TECHNICAL DATA** 

# FVF-SC4 | FlukeView Forms with Cable for 8845/8846



## Product overview: FVF-SC4 | FlukeView Forms with Cable for 8845/8846

Expand the power of the world's most rugged, accurate handheld test tools with FlukeView® Forms Documenting Software.

To address the increasing demands for reporting and documentation, Fluke presents FlukeView Forms documenting software. FlukeView Forms increases the power of your Fluke tool by enabling you to document, store and analyze individual readings or series of measurements, then convert them into professional-looking documents.

#### FlukeView® Forms Basic (FVF-BASIC)

Owners of Fluke 280 series, 180 series, 789 and 1550B, who do not need the full power of FlukeView forms, can use FlukeView® Basic version. Transfer data points from your meter to your PC and use the two standard, non-customizable forms to display your readings in table or graphical form. For a larger array of forms or to use FlukeView® Forms Designer to customize your forms, upgrade to FlukeView® Forms version 3.3 with FVF-UG.

#### **FlukeView Forms Compatibility Chart**

| <b>Model Nun</b> | nber Description  | Cable | Application Level |
|------------------|-------------------|-------|-------------------|
| Woodel Hall      | inder Description | Cubic | Application Ecvel |



| FVF-UG    | Software only upgrade, from FVF Basic to FlukeView Forms plus Designer** | No Cable included |                                  |
|-----------|--|-------------------|----------------------------------|
| FVF-SC2   | Fluke 280 Series, 53-II B and 54-II B, 789, 1550B, 1653, 180 Series*     | USB / IR          | FlukeView Forms plus<br>Designer |
| FVF-SC4   | Fluke 8808A, 8845A, 8846A, 45*   | USB / Serial      |                                  |
| FVF-BASIC | Fluke 280 Series, 789, 1550B, 1653, 180 Series*                          | USB / IR          | FlukeView Forms BASIC            |
| FVF-SC5   | Software only**  | No Cable included | Flukeview Forms DASIC            |

<sup>\*</sup> Obsolete


FlukeView Forms supports the following meters:

- Fluke 287 and 289 (Model FVF-SC2)
- Fluke 180 Series Digital Multimeters (Model FVF-SC2)
- Fluke 1653 Installation Testers (Model FVF-SC2)
- Fluke-1550B MegOhmMeter (Model FVF-SC2)
- Fluke 53-II & 54-II Thermometers (Model FVF-SC1)
- Fluke 87-IV & 89-IV Digital Multimeters (Model FVF-SC1)
- Fluke 45 Bench Meter (Model FVF-SC3)
- Fluke 789 ProcessMeter™ (Model FVF-SC2)

<sup>\*\*</sup> For all instruments listed in table



### **Ordering information**



FVF-SC4
FlukeView Forms with Cable for 8845/8846



### Fluke. Keeping your world up and running.®

Fluke (UK) Ltd.

52 Hurricane Way Norwich, Norfolk NR6 6JB United Kingdom

Tel.: +44 (0)20 7942 0708 E-mail: cs.uk@fluke.com www.fluke.com

©2025 Fluke Corporation. All rights reserved. Data subject to alteration without notice.

03/2025

Modification of this document is not permitted without written permission from Fluke Corporation.