

TECHNICAL DATA

Fluke TPS FLEX 18 Flexible Current Probe




Specifications: Fluke TPS FLEX 18 Flexible Current Probe

General Specifications	
Measuring Range selectable per software	1 A to 100 A
	5 A to 500 A
Peak current for sinusoidal currents	240 A
	1350 A
Iinsic error	1%
Frequency Range	45 Hz to 3.0 kHz
Operating Voltage	300 V CAT IV
Phase Error	0.5°
Jaw Opening	45 cm length
	2 m cable
Errors in % of measuring range at 23°C \pm 2 K; 74°F \pm 2 K, for 48 to 65 Hz Phase angle error at nominal current Imax maximum current without time limit (for AC and DC shunts)	



Ordering information



Fluke TPS FLEX 18-TF

Flexible Current Probe



$\textbf{Fluke}. \ \textit{Keeping your world up and running.} \\ \textbf{@}$

Fluke Corporation

PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:

In the U.S.A. (800) 443-5853 In Canada (800) 36-FLUKE From other countries +1 (425) 446-5500 www.fluke.com ©2025 Fluke Corporation.

Specifications subject to change without notice.

04/2025

Modification of this document is not permitted without written permission from Fluke Corporation.