

**TECHNICAL DATA** 

# FVF-SC4 | FlukeView Forms with Cable for 8845/8846



## Product overview: FVF-SC4 | FlukeView Forms with Cable for 8845/8846

### Expand the power of the world's most rugged, accurate handheld test tools with FlukeView® Forms Documenting Software.

To address the increasing demands for reporting and documentation, Fluke presents FlukeView Forms documenting software. FlukeView Forms increases the power of your Fluke tool by enabling you to document, store and analyze individual readings or series of measurements, then convert them into professional-looking documents.

#### FlukeView® Forms Basic (FVF-BASIC)

Owners of Fluke 280 series, 180 series, 789 and 1550B, who do not need the full power of FlukeView forms, can use FlukeView® Basic version. Transfer data points from your meter to your PC and use the two standard, non-customizable forms to display your readings in table or graphical form. For a larger array of forms or to use FlukeView® Forms Designer to customize your forms, upgrade to FlukeView® Forms version 3.3 with FVF-UG.

#### FlukeView Forms Compatibility Chart

Model Number Description

Cable



FVF-UG	Software only upgrade, from FVF Basic to FlukeView Forms plus Designer**	No Cable included	
FVF-SC2	Fluke 280 Series, 53-II B and 54-II B, 789, 1550B, 1653, 180 Series*	USB / IR	FlukeView Forms plus Designer
FVF-SC4	Fluke 8808A, 8845A, 8846A, 45*	USB / Serial	
FVF-BASIC	Fluke 280 Series, 789, 1550B, 1653, 180 Series*	USB / IR	FlukeView Forms BASIC
FVF-SC5	Software only**	No Cable included	FILKEVIEW FULLIS DASIC

\* Obsolete


\*\* For all instruments listed in table

FlukeView Forms supports the following meters:

- Fluke 287 and 289 (Model FVF-SC2)
- Fluke 180 Series Digital Multimeters (Model FVF-SC2)
- Fluke 1653 Installation Testers (Model FVF-SC2)
- Fluke-1550B MegOhmMeter (Model FVF-SC2)
- Fluke 53-II & 54-II Thermometers (Model FVF-SC1)
- Fluke 87-IV & 89-IV Digital Multimeters (Model FVF-SC1)
- Fluke 45 Bench Meter (Model FVF-SC3)
- Fluke 789 ProcessMeter™ (Model FVF-SC2)



### **Ordering information**



#### FVF-SC4

FlukeView Forms with Cable for 8845/8846



#### Fluke. Keeping your world up and running.®

Fluke Corporation PO Box 9090, Everett, WA 98206 U.S.A. For more information call:

In the U.S.A. (800) 443-5853 In Europe/M-East/Africa +31 (0)40 267 5100 In Canada (800)-36-FLUKE From other countries +1 (425) 446-5500 www.fluke.com/en-th

©2025 Fluke Corporation. Specifications subject to change without notice. 04/2025

Modification of this document is not permitted without written permission from Fluke Corporation.