

## TECHNICAL DATA

## Fluke BTL-A Voltage/Current Probe Adapter



### Product overview: Fluke BTL-A Voltage/Current Probe Adapter

Voltage/current probe adapter for Fluke 500 Series Battery Analyzers. The BTL-A allows connection of standard 4mm banana plug test leads or current clamp adapter. Allows the BT521 Series Battery Analyzer to make AC and DC voltage and current measurements using the Fluke i410 AC/DC Current Clamp.

## Ordering information



### Fluke BTL-A

Voltage/Current Probe Adapter

---

**Fluke.** *Keeping your world up and running.®*

**Fluke Europe B.V.**

P.O. Box 1186  
5602 BD Eindhoven  
The Netherlands  
[www.fluke.com/en](http://www.fluke.com/en)

©2025 Fluke Corporation. All rights reserved.  
Data subject to alteration without notice.  
04/2025

**For more information call:**

In Middle East/Africa  
+31 (0)40 267 5100

**Modification of this document is not permitted  
without written permission from Fluke  
Corporation.**