

TECHNICAL DATA

Fluke TPS Clamp 10 A/1 A Clip-on Current Transformer



Specifications: Fluke TPS Clamp 10 A/1 A Clip-on Current Transformer

General Specifications	
Measuring Range selectable per software	0.01 A to 1 A 0.1 A to 10 A
Peak current for sinusoidal currents	3.7 A 37 A
Intrinsic error	0.5%
Frequency Range	40 Hz to 10 kHz
Operating Voltage	300 V CAT IV
Phase Error	0.5°
Jaw Opening	15 mm diameter or 15 x 17 mm bus bars
Errors in % of measuring range at 23°C ± 2 K; 74°F ± 2 K, for 48 to 65 Hz Phase angle error at nominal current I _{max} maximum current without time limit (for ac and dc shunts)	

Ordering information



Fluke TPS CLAMP 10A/1A

Clip-on Current Transformer

Fluke. *Keeping your world up and running.®*

Fluke Europe B.V.

P.O. Box 1186
5602 BD Eindhoven
The Netherlands
www.fluke.com/en

©2025 Fluke Corporation. All rights reserved.
Data subject to alteration without notice.
03/2025

For more information call:

In Middle East/Africa
+31 (0)40 267 5100

**Modification of this document is not permitted
without written permission from Fluke
Corporation.**