

Datos técnicos

## A40B-ADAPT/LC | Adaptador de macho LC a macho LC



### Descripción general del producto: A40B-ADAPT/LC | Adaptador de macho LC a macho LC

This adapter permits connecting current sources with LC female current connectors to A40B LC female shunt input connectors (the 50 A and 100 A shunts). This can also be used with the A40B ADAPT/LCN if a female mating connector is required.

## Modelos



### **A40B-ADAPT/LC**

Adaptador de macho LC a macho LC

---

**Fluke.** *Manteniendo su mundo en marcha.*

**Fluke Corporation**  
Everett, WA 98206 EE.UU.

**Para obtener información adicional En EE. UU.**  
**(800) 443-5853**

**En Europa/Medio Oriente/África**  
**+31 (0)40 267 5100**

**En Canadá (800)-36-FLUKE**  
**www.fluke.com**

**Latin America**  
Tel: +1 (425) 446-5500  
[www.fluke.com/es-ar](http://www.fluke.com/es-ar)

©2025 Fluke Corporation. Reservados todos los derechos. Impreso en los Países Bajos. Información sujeta a modificación sin previo aviso.  
04/2025

**No está permitido modificar este documento sin autorización por escrito de Fluke Corporation.**