

Data teknis

# Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator



### Fitur utama

- 50 ohm coaxial feedthrough
- Provides proper cable termination
- Prevents coaxial cable reflections

# Ikhtisar Produk: Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator

Terminator Kabel TRM50 Coaxial Feed-through BNC Male ke BNC Female

## Spesifikasi: Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator

Spesifikasi	
Impedansi	50 Ohm
Voltase Maks melewati ground	1000V CAT III



Daya maks	1W
Daya maks	1 4 4



## Model



#### **Fluke TRM50 Coaxial Cable Terminator**

Fluke TRM50 Coaxial Cable Terminator

#### Includes:

• Two TRM50 Coxial Cable Terminators



### Fluke. Memastikan aktivitas Anda terus berjalan dan beroperasi.

Fluke Corporation

PO Box 9090, Everett, WA 98206 U.S.A.

BUT. FLUKE SOUTH EAST ASIA PTE LTD

Menera Satu Sentra Kelapa Gading #06-05 JI. Bulevar Kelapa Gading Kav. LA# No. 1

Summarecon Kelapa Gading Jakarta Utara 14240

Indonesia

Tel: +62 21 2938 5922 Email: info.asean@fluke.com

www.fluke.com/id

©2025 Fluke Corporation. Specifications subject to

change without notice.

03/2025

In Europe/M-East/Africa +31 (0)40 267 5100

In Canada (800)-36-FLUKE

For more information call:

In the U.S.A. (800) 443-5853

Modification of this document is not permitted From other countries +1 (425) 446-5500 without written permission from Fluke www.fluke.com

Corporation.

<sup>4</sup> Fluke Corporation Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator