


Dados técnicos

Fluke SW90W FlukeView ScopeMeter Software



Características principais

- For ScopeMeter(R) 190 Series II and 120 Series
- Windows XP/Vista/Windows 7/Windows 10
- Requires one free RS-232 port (COM port) or a free USB-Port
- Requires optional PM9080 RS-232 Adapter/Cable or an optional OC4USB-cable (190C Series, 120 Series)

Note: 190 Series II comes with USB-port and USB-cable included. For 190 Series II no additional hardware is required.

Descrição do produto: Fluke SW90W FlukeView ScopeMeter Software


FlukeView-1 software adds PC power to your Fluke ScopeMeter test tool

FlukeView-1 ScopeMeter software helps you get more out of your [ScopeMeter 190 Series II Test Tool](#) by:

- **Documenting:** Transfer screens, waveforms, and measurement data from the ScopeMeter Test Tool to your PC for printing, or to import data to other programs.
- **Archiving:** Store and retrieve waveforms with text annotations and create your own library for easy reference and comparison.
- **Analysis:** Gather valuable measurement data and enable cursor measurement to reveal relationship and conditions.

Extended recording of up to four user-selected measurements help you monitor and analyze slow moving signals and related events. Upload waveforms to the PC and use cursors for detailed measurements. Perform waveform analysis, including analyzing harmonics.

Modelos



Fluke SW90W

Fluke. *Keeping your world up and running.®*

Fluke Ibérica, S.L.
Pol. Ind. Valportillo
C/ Valgrande, 8
Ed. Thanworth II · Nave B1A
28108 Alcobendas
Madrid
Tel: +34 91 414 0100
E-mail: cs.es@fluke.com
www.fluke.pt
©2025 Fluke Corporation. Todos os direitos reservados.
Os dados fornecidos estão sujeitos a alterações sem aviso prévio.
04/2025

AresAgante, Lda.
Rua Caminho das Congostas, 320
4250-159 Porto
Tel: +351 2 2832 9400
E-mail: geral@aresagante.pt
www.aresagante.pt

A modificação deste documento não é permitida sem a autorização escrita da Fluke Corporation.