

## TECHNICAL DATA

# 9117 Annealing Furnace



## Key features

- Anneals both SPRTs and HTPRTs.
- Guards against contamination.
- Fully programmable controller specifically designed for the annealing process.

## Product overview: 9117 Annealing Furnace

All HTPRTs and SPRTs are subject to mechanical shock no matter how carefully you handle them. This shock changes the resistance characteristics of the platinum and shows up as temperature measurement errors. Annealing relieves the stress on the platinum sensor caused by mechanical shock and is recommended by NIST prior to any calibration of an SPRT.

In addition to removing mechanical strain, annealing also removes the oxidation from sensors that have been used for long periods at temperatures between 200 °C and 450 °C. Oxidation impacts the purity of the element and therefore the accuracy of temperature readings. Oxide is easily removed by annealing at 660°C for one or two hours.

During the annealing process, contamination must be controlled. At temperatures above 500°C, the lattice structure of a quartz sheath is transparent to metal ions. The thermometer must be cleaned and all contaminating materials removed from its sheath. Annealing should only be done in a furnace that's designed to avoid emitting metal ions during its heating cycle. Hart solves this problem in its 9117 furnace by using a quartz-encased graphite block that is specially prepared to guard against contamination before assembly.

The furnace also has a programmable controller specifically designed for the annealing process. As a manufacturer of SPRTs, Hart metrologists understand every aspect of SPRT use and calibration procedures, including the annealing process. We use this furnace in our own lab, so we know exactly how well it works.

## Specifications: 9117 Annealing Furnace

Specifications	
<b>Temperature Range</b>	300 °C to 1100 °C
<b>Stability</b>	±0.5 °C
<b>Uniformity</b>	±0.5 °C at 670 °C (over boom 76 mm [3 in])
<b>Power</b>	230 VAC (±10 %), 50/60 Hz, 12 A, 2500 W
<b>Display Resolution</b>	0.1 °C below 1000 °C 1 °C above 1000 °C
<b>Display Accuracy</b>	±5 °C
<b>Thermal Wells</b>	Five: 8 mm diameter x 430 mm long (0.31 x 16.9 in)
<b>Cooler</b>	PID, ramp and soak programmable, thermocouple sensor
<b>Over-Temp Protection</b>	Separate circuit protects furnace from exceeding rated temperature limit
<b>Exterior Dimensions (HxWxD)</b>	863 x 343 x 343 mm (34 x 13.5 x 13.5 in)
<b>Weight</b>	28 kg (61 lb.)
<b>Communications</b>	RS-232

## Ordering information



### **9117**

Annealing Furnace (includes Model 2129 Alumina Block)

---

### **2129**

Spare Alumina Block, 5 wells

---

**Fluke.** *Keeping your world up and running.®*

**Fluke Corporation**  
PO Box 9090, Everett, WA 98206 U.S.A.

**For more information call:**  
In the U.S.A. (800) 443-5853  
In Europe/M-East/Africa  
+31 (0)40 267 5100  
In Canada (800)-36-FLUKE  
From other countries +1 (425) 446-5500  
[www.fluke.com/en-th](http://www.fluke.com/en-th)

©2025 Fluke Corporation. Specifications subject to  
change without notice.  
04/2025

**Modification of this document is not permitted  
without written permission from Fluke  
Corporation.**