

TECHNICAL DATA

2019-DCB Fluid Level Adapter | Fluid Level Adapter



Product overview: 2019-DCB Fluid Level Adapter | Fluid Level Adapter

The 2019 fluid level adapter slides directly into the test wells of the Fluke Calibration 7030, 7013, and 7100 calibration baths, for glass thermometer calibration applications.

The fluid level adapter creates a positive bath fluid surface. The bath fluid in the test well is pumped up to the surface of the bath and kept there. This puts the glass thermometer meniscus above the edge of the bath test well for clear viewing during calibration. The clear acrylic adapter cover protects the bath fluid from ambient temperature effects for better bath stability. The cover can be drilled for any size probe. The adapter is easily pulled from the bath test well to allow more room during calibration of other thermometers and sensors.

Ordering information



2019-DCB-ADAPTER

Fluid Level Adapter

Fluke. *Keeping your world up and running.®*

Fluke (UK) Ltd.
52 Hurricane Way
Norwich, Norfolk
NR6 6JB
United Kingdom
Tel.: +44 (0)20 7942 0708
E-mail: cs.uk@fluke.com
www.fluke.com

©2025 Fluke Corporation. All rights reserved.
Data subject to alteration without notice.
04/2025

**Modification of this document is not permitted
without written permission from Fluke
Corporation.**