

TECHNICAL DATA

5500A/COIL | 50-Turn Current Coil



Product overview: 5500A/COIL | 50-Turn Current Coil

Supports the calibration of clamp-type current meters<

The 50 Turn 5500A/COIL is used as a tool for calibrating clamp type current meters that operate by two different principles -- as current transformers (AC only), and by the Hall Effect (Both AC and DC). It is impractical to calibrate 1000A rated current clamp meters using a 1000A source. However, by using the 50 turns of the 5500A/COIL in conjunction with a current calibrator you can effectively multiply the current of the current calibrator by a factor of 50 to support the calibration and verification of these clamp-on current meters.

Specifications: 5500A/COIL | 50-Turn Current Coil

General Specifications

| Number of Tus | 50 | |
|-----------------------------|---|--|
| Maximum Current | 11A rms, continuous 20A rms, 2 minutes | |
| Maximum Duty Cycle Derating | < 11A, continuous > 11A, 2 minutes ON, 8 minutes OFF | |



| Maximum Voltage | 3V rms | | |
|--|---|--|--|
| Frequency of Operation | DC, 45-440 Hz | (should not exceed rms Voltage rating) | |
| | For the 5500A Current Output: | DC, 45-65 Hz, 0-11A | |
| | | 65-440 Hz, 0-2.19999A | |
| | For the 5520A Current Output: | DC, 45-65 Hz, 0-20A | |
| | | 65-440 Hz, 0-2.99999A | |
| | | This specification assumes that a Fluke 80i-600 Clamp Meter or equivalent is aached. Other clamp meters may limit the 5500A/5520A Current Output drive capability to less than the above. | |
| Uncertainty Due to Clamp Meter/Coil Interaction | ± (0.25% of effective output + 0.5A), for toroidal-wound current clamps, such as the Fluke 80I and 80I-1000. | | |
| | ± (0.50% of effective output + 0.5A), for current clamps like the Fluke 80i-kw, 80i-400, 80i-410, 80i-500, 80i-1010, Fluke 31, Fluke 33, or equivalent. | | |
| Calibration Documentation | Statement of calibration practices included; With 17025 accredited report | | |
| Minimum Inside Diameter of Clamp Jaws | 2.54 cm (1 in.) | | |



Ordering information



5500A/COIL 50-Turn Current Coil



Fluke. Keeping your world up and running.®

Fluke (UK) Ltd. 52 Hurricane Way Norwich, Norfolk NR6 6JB United Kingdom Tel.: +44 (0)20 7942 0708 E-mail: cs.uk@fluke.com www.fluke.com ©2025 Fluke Corporation. All rights reserved. Data subject to alteration without notice. 04/2025

Modification of this document is not permitted without written permission from Fluke Corporation.