

TECHNICAL DATA

2523-156 Isolator | RS-232 Optical



Product overview: 2523-156 Isolator | RS-232 Optical

Using RS-232 while taking data with your 1523 or 1524 Reference Thermometer may result in a ground loop. Ground loops and electrical interference may result in inaccurate measurements if proper precautions are not taken. One method of breaking a ground loop is to use an optically coupled isolator. The Isolator breaks the electrical ground loop by only communicating data, using light. The optically coupled isolator is connected between the personal computer and the RS-232 cable to the 1523/1524.

- RS-232 optical isolator for the 1523 or 1524 Thermometer Readout
- 12 V dc, 120 V

Ordering information



2523-156 Isolator

RS-232 Optical



Fluke. *Keeping your world up and running.®*

Fluke Corporation
PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:
In the U.S.A. (800) 443-5853
In Canada (800) 36-FLUKE
From other countries +1 (425) 446-5500
www.fluke.com

©2025 Fluke Corporation.
Specifications subject to change without notice.
04/2025

**Modification of this document is not permitted
without written permission from Fluke
Corporation.**